




800-331-4362  
5747 West Isabella Road  
Mt. Pleasant MI 48858

## Horizontal Mirror Assembly



All Mirror Panels come with two pre-installed aluminum angle brackets for wall mounting. Remove these brackets if you are using the Alva's mirror base. Keep the clear plastic sheet over the mirror face to protect it while mounting the bases.

1) Open 'X' Brace and secure ends to nuts on 'T' Bars using the 4 Hex bolts provided. Put Hex Bolts

in all the way but only finger tight to allow adjustment when attaching Bumper Guard.

2) Attach Bumper Guard to tabs in 'T' Bars using the 4 Countersink Bolts provided. Place rounded corner of Bumper Guard away from vertical square tube of 'T' Bar. Tighten these Countersink Bolts completely with a #2 Phillips-head screwdriver.

3) Now tighten the 4 Hex Bolts with a 9/16" wrench.

4) Have a helper hold Mirror Panel centered on base. Side edges of mirror frame should be centered and flush with side vertical edges of the 'T' Bar. Drill drive four 1 1/2" Self-drilling Screws through the holes in vertical square tube of 'T' Bar and Mirror Panel's aluminum frame. Tighten screws up to the point where the sponge pads on 'T' Bar begin to slightly compress. Do not press excessively on mirror surface. Be careful not to over tighten screws to avoid stripping.

5) Plastic protective cover may now be removed from Mirror Panel.

6) Drill drive three 3/4" Self-drilling Screws through the holes in bottom of Bumper Guard, securing the Bumper Guard to the bottom of Mirror Panel frame. Do not over-tighten screws.

Alva's recommends that all prospective Glassless mirror customers obtain a 12" x 8" sample of the mirror panel from us before purchase to ensure that the product is appropriate for their needs. Due to the uniqueness of this product, most people are not familiar with it.

All customers must pay Alva's standard return policy of 25% re-stock fee if an order is cancelled after 24 hours of being placed, in addition to shipping fees if the order has already been shipped. This is why we encourage you to see a sample before purchase.

If your mirror has accumulated excessive dust and debris, before attempting to clean the mirror, use compressed air (i.e. Dust Off which can be found in most photographic stores) to make sure all dust and debris are off the mirror.

Use a clean 100% cotton or optical grade cleaning cloth (no lint) and Windex. Apply Windex to cloth until cloth is damp (saturated) but not dripping. Clean the mirror in one direction then stroke using a fresh part of the cloth after each pass.

If you have any questions, please call us at 1-800-331-4362.